

Non-Newtonian Fluids Require Specialized Planning for Variable Viscosities

The changing properties of wastewater and other fluids can cause unexpected pump performance.

By **Bill Blodgett**
LobePro Rotary Pumps

Knowing a fluid’s viscosity is essential to properly sizing piping and pumps. The viscosity of all fluids changes with temperature—the higher the temperature, the lower the viscosity. For Newtonian fluids, only temperature changes viscosity. However, non-Newtonian fluids’ viscosities also change for other reasons. Understanding these reasons is critical to efficiently pump this common type of fluid.

Time-Dependent Viscosity Changes

Thixotropic fluids thicken when sitting but thin over time when stressed. A single sharp impact does not appreciably reduce a thixotropic fluid’s viscosity. However, continuous shearing usually thins the liquid. Examples of thixotropic fluids include many wastewater sludges, drilling fluids, paints, flocculants, bentonite mixtures, honey, molasses and

Most non-Newtonian fluids thin both as a result of the amount of force and the length of time the force is applied.

ketchup. Most thixotropic fluids are also shear-thinning, meaning the force and the length of shear time reduces the fluid’s viscosity.

Rheopectic fluids do just the opposite. They get thinner when sitting and thicker when stressed over time. Printing ink is one example, but rheopectic fluids are fairly rare.

Time-Independent Viscosity Changes

Pseudoplastic, or shear-thinning, fluids’ viscosities decrease with the force of stress. Most shear-thinning fluids are also thixotropic. Ketchup is a good example of this type of fluid. When trying to get ketchup out of a glass bottle,

usually the bottle has to be turned upside down and shaken or hit. A combination of sufficient force over sufficient time is required to reduce the ketchup’s viscosity enough for it to flow.

Dilatant, or shear-thickening, fluids’ viscosities increase with the force of stress rather than the length of time of stress. A familiar example is the silicone-polymer toy Silly Putty, which is very soft in the hand but becomes hard when thrown down. Most dilatant fluids are also rheopectic. For example, turning cream into whipped cream takes the right combination of time and force.

Implications for Pump and Pipe Sizing

To effectively size pumps, motors and piping to meet performance specifications, operators need to know the minimum and maximum viscosity of fluids. Viscosity can affect pump suction and discharge pressure requirements and pump performance.

Table 1. Viscosity-induced friction loss in discharge pipe (Graphics courtesy of LobePro Rotary Pumps)

Viscosity (centistokes)	Friction loss in psi per 100 feet
110	8
220	16
440	32
880	64

Viscosity-induced friction losses in discharge pipe can be considerable. For example, the pounds per square inch (psi) loss per 100 feet when pumping 50 gallons per minute (gpm) of fluid with a specific gravity of 1 through new, schedule 40, 2-inch steel pipe is shown in Table 1 (see page 72).

This is in addition to the velocity friction loss commonly included in hydraulic calculations based on water. While knowing the highest viscosity is critical, knowing the lowest viscosity is also important, because this may result in more slip and lower pump output. Pump suppliers should be able to provide accurate estimates of pump output at minimum and maximum viscosity. Determining the viscosity of a non-Newtonian fluid can be challenging because the effects of time, force and temperature on viscosity must be understood.

Modeling Non-Newtonian Effects for Wastewater

Figure 1 shows a practical way to model friction losses for wastewater sludge. The chart is taken from the Environmental Protection Agency’s (EPA) Standard 625/1-79-011. The thicker a particular type of wastewater sludge is, the greater its viscosity.

Figure 1 shows, for instance, that pipe friction loss when pumping 5 percent untreated municipal sludge will be approximately four times as much as when water is pumped. If several sets of discharge pipe that are 100 feet long are specified, larger pipe may be required to obtain the lowest long-term cost. The EPA guidelines may be used as a rough estimate provided pipe velocities are between 2.5 and 8 feet per second and the

pipe is not seriously obstructed by grease or other materials. Pumping wastewater sludge at low velocities in a pipe may require more horsepower than pumping at higher velocities. This is counter-intuitive but results from solids dropping out of suspension and gradually reducing pipe size.

The EPA guideline for pumping wastewater sludge also does not consider thixotropic behavior. As a result, when starting a pipeline shutdown for longer than one day, higher pressures may be required than would be calculated using the graph. Friction losses may be much higher in suction pipe. Care must be taken when pumping shear-thinning, thixotropic fluids that the suction piping is designed to allow fluid to continue to feed into the pump after a weekend shutdown in cold weather. A special problem of wastewater sludge is that, unlike water, it compresses under pressure. A static shear stress test can be obtained to accurately determine the force required to overcome initial resistance to flow for thixotropic fluids.

A research team in Canada developed another approach to obtaining a reasonably accurate model. They did a series of empirical studies at wastewater treatment plants. Based on these results, they proposed adjusting the Hazen-Williams pipe coefficient as a simplified way of including thixotropic resistance in the required hydraulic calculations (see Table 2).

For example, consider a wastewater treatment


plant that uses cast iron asphalt lined pipe. The Hazen-Williams friction constant for this pipe is 100 if pumping 100-degree F water. Using Table 2, the Hazen-Williams pipe friction constant is adjusted to 61 (100 times 0.61) for 4 percent municipal wastewater sludge.

Guidelines for Other Non-Newtonian Fluids

Practical guidelines are available for most non-Newtonian fluids, which thin as a result of force, time and temperature. Most experienced users have developed successful

Table 2. Hazen-Williams adjustment coefficients

Municipal sludge-% of solids	Hazen-Williams adjustment coefficient for pipe based on 100 degrees Fahrenheit ¹
0	100
2	81
4	61
6	45
8.5	32
10	25



guidelines for pumping their fluids. If the user is experiencing difficulties, however, these cannot be resolved economically without knowing minimum and maximum viscosities and what causes them.

Conclusion

All fluids become less viscous as a result of heat. Most non-Newtonian fluids thin as a result of the amount of force and the length of time the force is applied. To accurately model pump performance, the pumped fluid's minimum and maximum viscosity must be known. The viscosity range of non-Newtonian fluids can be wide and have significant effects on pump performance and pipe sizing. ■

Reference

1. Environmental Engineers' Handbook, Second Edition. By David H. F. Liu, Béla G. Lipták Page 671. The adjustment is suggested because municipal sludge thickens when sitting in a discharge pipe overnight. This can result in much higher startup pipe friction. These Hazen-Williams Coefficient adjustments are based on empirical studies.

Bill Blodgett is president of LobePro Rotary Pumps. Blodgett holds undergraduate and graduate degrees in economics and finance from University of Pennsylvania and the University of Chicago. Blodgett is the 1987 winner of Northwood University's National Business Leader Award, the former director of entrepreneurship and current treasurer of Palm Beach Atlantic University. He is also active in many charitable organizations. LobePro Rotary Pumps provides engineered pumping solutions in difficult applications such as municipal sludge, drilling mud, oil refining, corrosives and waste oil. For more information, email Blodgett at billb@lobepro.com or visit lobepro.com.



ROTARY LOBE SLUDGE PUMPS FOR SLUDGES/SLURRIES/CORROSIVES



Gear housing is separated from wet end and mechanical seals


Rebuildable design offers the best of cartridge seal and a component seal in ONE while reducing repair costs 50 to 80%.

Wear plates are reversible for double the wear.

Helical four wing lobes provide smooth low shear flow. Lobes available in many materials.

Wear plates and housing segments are customized for abrasive, corrosive, and general applications.

Gears do not require timing by user



Shutdown protection available for contaminants and over pressure conditions

In Place wear part replacement at 1/3 the cost and time for equivalent PC pump.

Slow running. Non-contacting lobes permit dry running and pumping of abrasives.

Mechanical seals cooled by oil. No flush water required.

Self-priming to 25'. Reversible operation.

